



## What can the FoodCycler process?

- Most fruit and vegetables
- Meat, shellfish, and poultry scraps
- Cheese
- Beans, seeds and legumes
- Chicken and fish bones/ shells
- Coffee grounds, filters and tea bags
- Eggs and eggshells

### Limited quantities only:

- High sugar fruits (grapes, bananas, melon, oranges, and pineapple)
- Cake and bread
- Rice and pasta

## What can the FoodCycler NOT process?

- Hard, dense bones (beef, pork, lamb and bison)
- Candy
- Gum
- Cooking oils and greases
- Hard pits (peaches, apricots, and nectarines)
- Nuts and other hard shells
- Pineapple leaves
- Watermelon rinds
- String
- Sauces, jams, jellies and peanut butter



## What should be cut up before being added to the bucket?

- Fibrous herbs and plants (celery, parsley, etc.)
- Corn cobs and husks
- Paper towels and tissue
- Pineapple leaves
- Whole fruits and vegetables



## Steps to follow when adding food to the bucket:

- **ONLY** add food to the bucket when **OUTSIDE** of the FoodCycler unit.
- **FILL** to the line seen on the inside of the bucket, 1 in from the top.

## Steps to run a cycle, and what to do afterwards:

- Run a cycle by locking the bucket inside, and closing the lid latch.
- Press the button to start. The power symbol will glow blue to indicate it is running.
- Cycles will run 4-8 hours. The blue light will turn off when a cycle is complete.
- Remove the soil amendment and place soil into front flower pots and beds.